

UVS 2.0.11 Release Notes

Category	Summary	Fixed in Version
Enhancement	Limit the log size to avoid eMMC damage	2.0-10
BMC	Allow user to use BMC command line to configure network setting simultaneously on 8 Nodes	4.2.3
BMC	1. Add "Clear Mount & Reboot" before restore. Fix bug in Restore to Default.	4.2.3
BMC	Allow user to restore all 8 nodes simultaneously	4.2.3
BUG	Ruleset Failure domain of Erasure Profile always shows host while another failure domain was set	2.0-10
BUG	Update fails if update file larger then 10MB	2.0-10
BUG	sometimes Blank MAC address information when generating license request	2.0-10
BUG	nginx error after adding multiple root and chassis in crushmap	2.0-10
BUG	Display proper message if restore fails due to some reason	2.0-10
Enhancement	Use M.2 SSD as MON storage instead of eMMC	2.0-10
Enhancement	Show which node user is login in node console.	2.0-10
Enhancement	Add a confirmation before purge RBD snapshot.	2.0-10
General	Change the "Danger" to "Warning" when there is no UVS license or License expires	2.0-10
Enhancement	node shall sync with NTP after NTP configuration is pushed from UVS	2.0-10
Enhancement	Implement SOC watchdog in MARS400	2.0-11
Enhancement	Implement SOC watchdog in MARS200	2.0-11
Enhancement	Add "Clear mount & Reboot" to BMC "Maintenance" command due to new procedure of restore a node	2.0-11
Enhancement	implement SNMP as standard package on MARS 400/200	2.0-11
Enhancement	Upgrade MARS400 to CentOS7.5 and Ceph 12.2.7	2.0-11
Enhancement	Upgrade MARS200 to CentOS7.5 and Ceph 12.2.7	2.0-11